



ДАНИЯ


Шкаф книжный 1-створчатый



- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje



1006
30



1004
18



1038
38




1096
30



1097
30



1027
4



1020
2




1008
4




1028
4




1100
12




1099
1




1042
1






1024
3





1048
1







6



7

