


АЙНО


Шкаф книжный №3



RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje



1004
24



1096
44




1097
36




1008
8




1028
8



1039
24




1074
6




1042
2




1006
60





1099
2





1048
2








2




3





4




5





8



9

