

ДАНИЯ

Банкетка



- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje



1006
12



1004
6



1038
10




1096
10



1097
10



1027
4



1020
1



1008
4



1028
4

