


# 1-36

Верх / Top / Yläpuoli




- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje



1006  
**36**



1004  
**8**



1070  
**2**




1096  
**12**




1097  
**12**




1038  
**30**




1042  
**2**




1100  
**8**




1025  
**4**




1098  
**2**





1099  
**2**









**3**



**4**



# 5

