



1-55, 1-56, 1-57
2-50

Берх / Top / Yläpuoli



2-3, 2-4, 2-5

2-49, 2-51

2-53, 2-57

Берх / Top / Yläpuoli

 **TIMBERICA**

RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje



1038
100



1004
24



1006
28



1008
16



1096
32




1097
32




1027
16




1028
16



1070
3



1072
6




1042
3




1100
24




1040
8




1099
2








1098
2




1074
4

















7



8

9





x4