


1-37, 1-54

1-36

Низ / Bottom / Alapuoli



- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje



1006

36

1008

12

1004

16

1027

24

1028

24

1074

6


1027

12


1028



12

1038



30

1049

3



4



5

6

