

2-18

2-27

Низ / Bottom / Alapuoli



 **TIMBERICA**

RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje



1006
48



1038
30



1004
26



1008
19



1027
28



1028
28



1027
16




1028
16




1013
18




1010
8




1034
1







1071
7




1049
4








3




4







5

6



7





12

