


ДАНИЯ

Шкаф 2-створчатый



- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje



1022
4



1004
28



1038
80




1028
40



1027
40



1006
58



1047
2




1008
4




1039
32



1040
24




1049
2




1024
6


1




2





3




4







8



9





11

