

2-8, 2-9

2-10, 2-11

Берх / Top / Yläpuoli



1-16

Берх / Top / Yläpuoli



- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje



1006
22



1100
8



1004
8




1038
40




1096
20




1097
20



1072
4




1042
2




1099
2




1036
2







1098
2




1070
2







5



6

