


Ари-Прованс

Шкаф книжный №3



- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje



1006
43



1008
4



1004
12



1096
24




1097
24



1038
34




1074
2



1042
1




1039
16




1024
3




1040
16







1099
2








1075
2

















10



11



12

