


2-23

Берх / Top / Yläpuoli



- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje



1010
4



1004
24



1097
44




1040
8



1096
44




1070
2



1072
4




1013
2




1042
2




1006
20




1099
2




1098
2





1034
1







3





4

5



6



7

