


АЙНО

Тумба ТВ




 **TIMBERICA**


RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje



1034
1



1004
60



1038
50



1006
44



1028
24




1027
24



1039
8




1008
8



1011
30




1010
4




1020
2




1021
1





1049
4




1024
2







2




3





4




5







8





9



10



11



12

