



Бетти

Модуль №5



1004
8



1038
18




1097
18




1096
18



1028
2




1024
2




1042
1



1006
26



1049
2



RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje

