

ДАНИЯ

Шкаф 1-створчатый



- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje



1022
1



1004
14



1038
50




1028
31




1027
31



1006
18




1045
4




1024
3




1




2





5



9

