


2-1, 2-16, 2-56

2-2, 2-19, 2-62, 2-63, 2-65, 2-66, 2-69

Низ / Bottom / Alapuoli
























 **TIMBERICA**



RU Инструкция по сборке


EN Assembly instruction

FI Koontaohje











x2




x3


6




7




8



9



11



12

