


АЙНО


Сундук



RU Инструкция по сборке

EN Assembly instruction


FI Koontaohje



1034
1



1004
8




1010
4



1028
8




1027
8




1011
8




1006
8




1024
2




1





2





3



4

