

АЙНО

Стеллаж №2, №4, №5



RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje



1006
20



1008
4



1004
12




1096
22




1097
22




1038
50




1074
2






1098
2




1048
1










5



6

