

ДАНИЯ


Шкаф комбинированный



- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje



1022
4



1045
4



1010
4



1038
70



1004
30




1028
55




1027
55





1006
50






1050
2





1024
4





3







4




5






6



7







9

