

ДАНИЯ

Сервант 3-створчатый №3



RU Инструкция по сборке
EN Assembly instruction
FI Koontaohje



1006
88



1004
26



1038
98



1096
42



1097
42



1027
12



1020
7




1008
12




1028
12




1040
12




1042
4






1024
9





1048
3









9

