

1-29, 1-30, 2-6
2-32, 2-33, 2-58
2-59, 2-60, 2-61
2-62

Берх / Top / Yläpuoli












1-58, 1-59, 1-60
2-63, 2-64, 2-19
2-22


Берх / Top / Yläpuoli

 **TIMBERICA**


RU Инструкция по сборке
EN Assembly instruction
FI Koontaohje



1




2




2/5


3



4



5



6

