

2-21, 2-24, 2-26

Верх / Top / Yläpuoli



 **TIMBERICA**

RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje




1004
8



1096
18



1097
18



1072
4



1038
20



1006
24




1070
2




1036
2




1100
8




1099
2





1042
2




1098
2









6

