


2-55

2-61, 2-64, 2-67, 2-68

Низ / Bottom / Alapuoli






















 **TIMBERICA**



RU Инструкция по сборке



EN Assembly instruction

FI Koontaohje












5





6



7





10

