


АЙНО

Шкаф 3-створчатый №4



RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje




1006
58



1097
44



1004
28



1042
3




1096
44




1074
3




1038
58





1099
2




1047
2




1024
9






4



5



6

