


ДАНИЯ

Шкаф 4-створчатый №2



- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje



1006
60



1004
34




1038
52




1040
16



1097
71



1096
71




1099
2




1020
4




1036
1




1042
3



1024
6



1026
3



1047
2

