


1-37, 1-54

1-36

Низ / Bottom / Alapuoli



- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje



1006
36



1008
12




1004
16



1027
24



1028
24



1074
6




1027
12




1028
12






1038
30





1049
3







4



5

6

